



OWNERS GUIDE

REYNOLDS CYCLING CARBON FIBER HANDLEBAR INSTALLATION, CARE & MAINTENANCE

Reynolds Carbon Handlebars have been designed and manufactured with strict quality controls and tolerances. Every effort has been made to manufacture a part that is free of defect in materials and workmanship.

Please read and follow these instructions. They are important for the correct use and installation of your Reynolds handlebar. Installation should be completed by a qualified bicycle technician using appropriate tools. Reynolds assumes no liability for products which are improperly installed.

PRODUCT SPECIFICATIONS

Reynolds handlebar clamp diameter: 31.8mm

PREPARATION FOR INSTALLATION

Before installation confirm that the stem clamp diameter is the same as the handlebar clamp diameter. Do not modify the handlebars or stem in any way. Do not install the handlebar if the stem diameter does not match the handlebar clamp diameter.

INSTALLATION

Be sure to follow the stem manufacturer's instructions for proper installation. Reynolds assumes no liability for damage caused by installing other manufacturer's products.

- Prior to installation, clean the clamping surfaces of both the stem and handlebar. Inspect both the stem and handlebar for dents, gouges, cracks and deep scratches. If any of these are present, do not continue installation.
- Do not lubricate either surface.
- Prior to installing brake levers, or any other item, inspect the clamping mechanism for sharp edges. If any such edges are present, remove them with sandpaper. Do not use a rotating motion when installing any clamped item because this motion can cause gouges. If there is any resistance while installing any item, remove it and loosen the clamp mechanism. The 31.8mm center section is 105mm in length. Do not clamp any item outside of this range (See Figure 1).

MAINTENANCE

- For maximum service life regular maintenance must be performed
- Frequent inspection is essential. Before each ride, inspect for dents, gouges, cracks or deep scratches. Do not continue to use the handlebar if any are found. In the event of a major impact or accident, have a qualified bicycle dealer examine the handlebar before using the bicycle again. Do not attempt to straighten the handlebar.
- Before clamping any item to the handlebar, be certain that the clamping surfaces are free from sharp edges and the surfaces are free from lubricants.

LIMITED WARRANTY

Subject to the following limitations, terms and conditions, Reynolds Cycling ("Reynolds") warrants to the original retail purchaser that each Reynolds bicycle component purchased when new is free from defects in material and workmanship. This warranty expires one (1) year from the date of the original purchase of the Reynolds bicycle component from an authorized Reynolds dealer.

THIS WARRANTY DOES NOT COVER:

- Normal wear-and-tear.
- Any damage, failure or loss caused by accident, misuse, neglect, abuse, failure to follow instructions or warnings in assembly instructions.
- Any damage, failure, or loss caused by use of bicycles for stunt riding, ramp jumping, acrobatics, or other similar activities, or in any manner other than road cycling.
- Any damage, failure, or loss caused by the use of bicycles not intended for such use, as power driven vehicles.
- The original owner shall pay all labor charges connected with the repair or replacement of all parts. Under no circumstance does the limited warranty include the cost of shipment or transportation to or from Reynolds or an authorized Reynolds dealer.

WARRANTY CLAIM PROCEDURES

- Warranty service will be performed by Reynolds or a Reynolds authorized dealer. Proof of purchase must be provided. Transportation to and from Reynolds or a Reynolds authorized dealer is the responsibility of the purchaser.
- Reynolds will have the option of either repair or replacement at no charge for the defective product.
- If you elect to repair a defective product yourself or use the services of someone other than a Reynolds authorized dealer, or if you use a replacement part not supplied by Reynolds, Reynolds will not be liable for any damage, failure or loss caused by the use of such unauthorized service or parts.

See your Reynolds authorized dealer for your service, visit our website or write:

Reynolds Cycling, LLC
3392 West 8600 South
West Jordan, UT 84088
www.reynoldscycling.com

LIMITATIONS

Proof of purchase from an authorized Reynolds dealer is required for any limited warranty replacement or repair.

WARNING: Attachment of Quick Release Wheel to Fork or Frame. Proper operation of the quick release is essential to safe riding. Check the quick release before every ride, make sure it is properly secure. If it is not properly secure, the front wheel may wobble or disengage from the bicycle, which may result in serious bodily injury or death. If you do not fully understand its operation, see your authorized Reynolds dealer.

THE FOREGOING WARRANTIES ARE IN LIEU OF AND EXCLUDE ALL OTHER WARRANTIES NOT EXPRESSLY SET FORTH HERIN, WHETHER EXPRESS OR IMPLIED BY OPERATION OF LAW OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE.

THIS IS AN INTEGRATED AND FINAL STATEMENT OF REYNOLDS' LIMITED WARRANTY. REYNOLDS DOES NOT AUTHORIZE OR ALLOW ANYONE, INCLUDING IT'S AUTHORIZED DEALERS. TO EXTEND ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, FOR REYNOLDS. NO OTHER REPRESENTATION, AND NO STATEMENT OF ANYONE BUT REYNOLDS, INCLUDING A DEMONSTRATION OF ANY KIND BY ANYONE, SHALL CREATE ANY WARRANTY REGARDING THIS REYNOLDS BICYCLE COMPONENT. ALL OF THE REMEDIES AVAILABLE TO THE ORIGINAL OWNER ARE STATED HEREIN.

Reynolds shall in no event be liable for incidental or consequential losses, damage, or expenses in connection with its products. Reynolds' liability hereunder is expressly limited to the replacement of goods not complying with this warranty.

Some states do not permit the exclusion or limitation of implied warranties or consequential damages, so the proceeding limitations and exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights that may vary from state to state.